



+ PARTS LIST
No. 4

UAB „AGROTEKAS”
LT-44248, Kaunas, Lithuania,
ul. K. Donelaicio 62-1
tel. +370 656 50607
e-mail: export@agrotekas.com


OPERATOR'S MANUAL FLAIL MOWER




KS Profi 95, 115, 125, 135




KSH Profi 125, 135




KS 95, 115, 125, 135




KM 125, 155, 175




KMH 155, 175



KMH Profi 155F, 175F



KDX 180, 200, 220, 240



KDX Profi 180, 200, 220, 240

Translation of original user manual

EDITION III - 2020





DECLARATION OF CONFORMITY



According to the Regulation of the Minister of Economy of 21 October 2008 on essential requirements for machines (Official Journal, No 199, item. 1228) and the Directive of the European Parliament and Council Directive 2006/42/EC

UAB „AGROTEKAS”
K.Donelaičio g.62-1,
LT-44248 Kaunas, Lithuania

The person responsible for the preparation of the technical documentation of the machine:

Name and surname: GINTAUTAS RIMKUS adr: K. Donelaičio g. 62-1, LT-44248 Kaunas,

acting as the manufacturer, I declare with full responsibility that:

Machine:	FLAIL MOWER
Type/model:
Serial number:
Year of manufacture:
Function:

to which this declaration relates, complies with all relevant provisions contained in:

Directive of the European Parliament and Council Directive 2006/42/EC of 17 May 2006 on machinery (Acts. Office. EU L157 of 09.06.2006, p. 24-86);

Regulation of the Minister of Economy of 21 October 2008. (Official Journal No 199, item. 1228) on the essential requirements for machines

For evaluation of conformity the following harmonised standards apply:

PN-EN 4254-12:2012

PN-EN ISO 12100:2012

PN-EN ISO 4254-1:2013

and standards and regulations:

PN-ISO 3600:1998

PN-ISO 11684:1998

Minister of Labour and Social Policy, June 6, 2014 on maximum permissible concentration and intensity of harmful factors in the work environment (Official Journal, 2014 pos. 817);

This declaration of conformity loses its validity if the machine is changed or rebuilt without the permission of the manufacturer.

Operator’s manual is the basic equipment of the machine.

If the mower is used by another user, it should be in working condition and include the operator’s manual and declaration of conformity.



Direktorius
Gintautas Rimkus

2017.09.01 Kaunas

Place and date of issue

Name, position and signature of authorized person for making a declaration of conformity on behalf of the manufacturer

CONTENTS

1. INTRODUCTION	4
1.1. General terms of use.....	4
1.2. Intended use.....	5
1.3. Technical data.....	5
1.4. Identification of the machine	7
2. OPERATIONAL SEFATY AND PRECAUTIONS	8
2.1. Safety rules.....	8
2.2. Fire regulations	10
3. DESCRIPTION OF RESIDUAL RISK	11
4. WARNING PICTOGRAMS	11
5. GENERAL INFORMATION	16
5.1. Introduction.....	16
5.2. Design of the mower.....	16
5.3. Delivery and receipt of the mower	20
6. SAFE OPERATION RULES	21
6.1. Preparing the tractor for operating the mower	21
6.2. Preparing the mower for operation	21
6.3. Adjusting mowing height	22
6.4. Operation	23
6.5. Moving from transport to working position	25
6.6. Moving KMH, KMH Profi, KDX, KDX Profi and KSH Profi from central to side position.....	25
6.7. Replacement of flail knives.....	25
6.8. Travelling on public roads	25
7. MAINTENANCE SERVICE	26
7.1. Regulation V-belts tension	28
8. HYDRAULIC SYSTEM.....	28
9. STORAGE	29
9.1. Preparing the mower for storage	29
9.2. Starting up the mower after storage period	30
10. LOCATION AND IDENTIFICATION OF MOWER MALFUNCTIONS	31
11. WITHDRAWAL OF MOWER FROM USE	31
12. WARRANTY CLAIM PROCEDURES	32

**READ THIS INSTRUCTION MANUAL
CAREFULLY BEFORE OPERATING THE
MOWER**

**THIS OPERATOR'S MANUAL IS CONSIDERED THE MOWER'S BASIC
EQUIPMENT
KEEP THIS MANUAL FOR FUTURE USE**

1. INTRODUCTION

The user receives this manual together with the grass mower at the sale point.

The user is responsible for being familiarized with the operator's manual carefully.

Expressions used in the operator's manual: left side, right side, back and front - refers to setting an observer facing face in the direction of machine travel. Whenever the operator's manual refers to the machine, it should be understood as flail mower.

1.1. General terms of use

- The mower to mow the short stem plants can be handled, operated only by those who are thoroughly familiar with the contents of the operator's manual, particularly with the information in the chapter "Operational safety and precautions". The same obligation applies to people carrying out repairs. The failure to follow proper operation may cause an accident or machine failure.
- The manufacturer provides the mower with the operator's manual, warranty card and parts listed in the section "Equipment". Please check received documents and the conformity of the machine number on the nameplate and the number listed in the documents.
- The manufacturer does not allow arbitrary changes in the construction of mower. A proposal for changes and improvements must be reported and agreed with the design department or service manufacturer.
- Any made changes without consulting, release the manufacturer from the results of arising from their introduction and void the warranty.
- Maintenance and operation of the mower inconsistent with operator's manual absolves the manufacturer of responsibility for the consequences resulting from improper use and causes loss the warranty.
- The mowers are subject to continuous development and therefore UAB "AGROTEKAS" reserves the right to make changes and improvements it deems appropriate.
- In case of any doubt or misunderstanding about the mower operation described in the operator's manual, please contact UAB "AGROTEKAS", supplier or service manufacturer with a request for exhaustive explanations.
- Keep this manual for future use.



NOTICE!

When operating the mower respect warnings and safety rules marked with this sign. This symbol indicates a warning about the threat to important information regarding the risks specified in the manual. If you see this symbol, beware the hazards and read the relevant information carefully and inform the other operators.



DO NOT OPERATE WHEN ANY PERSON REMAINS IN THE DANGER AREA OF 50 m

1.2. Intended use

The flail mower is intended to mow short stem plants (grasses, alfalfa, etc.) on permanent grassland (meadows), roadsides, squares, slopes, ditches, etc., shredding thinner trunks, smaller shrubs, weeds, etc. of less density.

The mower KS cooperates with tractors class 0.6 with a power of 7,5 kW/10 hp.

The mower KS Profi, KSH Profi cooperates with tractors class 0.6 with a power of 7,5 kW/10 hp.

The mower KM, KMH, KMH Profi cooperates with tractors class 0.9 with a power of 27 kW/36 hp.

The mower KDX, KDX Profi cooperates with tractors class 1.4 with a power of 41 kW/55 hp.



It is forbidden to use the machine for other purposes than those specified in the manual. Using the mower for other purposes shall be understood as improper. Performance and strict respect conditions regarding the use of the mower, proper maintenance and repair is also an integral part of the requirement of use according to specifications.

The manufacturer is not liable for damage or loss resulting from misuse of the mower as described above. The owner of the machine and/or machine operator is responsible for consequences of improper machine use.

1.3. Technical data

Tab. 1

Technical data of the flail mower KM, KMH, KMH Profi, KDX, KDX Profi

No.	Parameter	Unit of measure	Mower type															
			KM			KMH		KMH PROFİ		KDX				KDX PROFİ				
			125	155	175	155	175	155	175	180	200	220	240	180	200	220	240	
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	
1	General dimensions:																	
	-length	mm	779	779	779	864	864	820	820	965	965	965	965	967	967	967	967	967
	-width	mm	1370	1670	1870	1670	1870	1790	1890	1934	2134	2334	2534	1941	2141	2341	2541	2541
	-height	mm	778	778	778	852	852	940	940	927	927	927	927	936	936	936	936	936
2	Working width	m	1,25	1,55	1,75	1,55	1,75	1,55	1,75	1,8	2,0	2,2	2,4	1,8	2,0	2,2	2,4	2,4
3	Weight	kg	239	265	284	318	339	354	376	475	499	543	568	567	593	620	648	648
4	Number of flails	pcs.	20	24	28	24	28	24	28	26	28	32	34	26	28	32	34	34
5	Diameter of drum with flails	mm	108								127							
6	Stroke mower	-	-				hydraulic											
7	Stroke mowers from the tractor's the axle:																	
	to left	mm				771	871	870	871	859	1076	1079	1179	859	1075	1075	1175	1175
	to right	mm				1127	1227	1029	1227	1290	1272	1470	1570	1172	1274	1474	1574	1574
8	Request power take	KM/kW	16/12	26/19	36/27	26/19	36/27	26/19	36/27	60/45	70/52	80/60	90/67	60/45	70/52	80/60	90/67	90/67
9	Linkage category	class	I								II							

1	2	3	KM			KMH		KMH PROFI		KDX				KDX PROFI			
			4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
10	Recommended articulated - telescopic shaft for collaboration:																
	Nominal torque rotary	Nm	460					620									
	Nominal power	kW	26					35									
	Nominal rotations	rpm ¹	540														
	Length of the shaft L	mm	1000														
	Clutch	-	-														
	Top blade on the tractor side	pcs.	6														
	Top blade on the machine side	pcs.	6														
	Request power take	kW/KM	27/36					36/48									
	Safety sign	-	CE														
11	Rotations																
	PTO	rpm	540														
	drum with flails	rpm	2295					2141									

Technical data of the flail mower KS, KSP, KSHP

Tab. 2

No.	Parameter	Unit of measure	Mower type										
			KS				KSP				KSHP		
			95	115	125	135	95	115	125	135	125	135	
1	2	3	4	5	6	7	8	9	10	11	12	13	
1	General dimensions:												
	-length	mm	696	696	696	696	824	824	824	824	824	824	824
	-width	mm	1070	1270	1370	1470	1070	1270	1370	1470	1470	1470	1470
	-height	mm	694	694	694	694	1005	1005	1005	1005	1005	1005	1005
2	Working width	m	0,95	1,15	1,25	1,35	0,95	1,15	1,25	1,35	1,35	1,35	
3	Weight	kg	138	149	166	173	170	181	188	195	223	230	
4	Number of flails	pcs.	18	21	21	24	18	21	21	24	24	24	
5	Diameter of drum with flails	mm	76										
6	Stroke mower	-	-								hydraulic		
7	Stroke mowers from the tractor's the axle:												
	to left	mm	-								722		
	to right	mm	-								900		
8	Request power take	KM/kW	10/7,5	15/11	18/13	20/15	10,75	15/11	18/13	20/15	20/15	20/15	
9	Linkage category	class	I										

		KS					KSP				KSHP	
1	2	3	4	5	6	7	8	9	10	11	12	13
1	Recommended articulated - telescopic shaft for collaboration:											
	Nominal torque rotary	Nm	460									
	Nominal power	kW	26									
	Nominal rotations	rpm	540									
	Length of the shaft L	mm	1000									
	Clutch	-	-									
	Top blade on the tractor side	pcs.	6									
	Top blade on the machine side	pcs.	6									
	Request power take	kW/KM	27/36									
Safety sign	-	CE										
11	Rotations											
	PTO	rpm	540									
	drum with flails	rpm	1867									

The level of noise emission at the terminal $73.0 \hat{A} \pm 3.2$ dB.

1.4. Identification the machine

Data plate is mounted to the mower's upper metal housing in the place shown below in Fig. 1. Data plate includes identification data to enable identification of the mower.




Fig 1. Data plate location

2. OPERATIONAL SEFATY AND PRECAUTIONS

Keep the general work safety rules when operating the mower at any work maintenance and repair work.



NOTICE!

This manual is the basic equipment of the machine. It should be kept throughout the life of the machine. If the mower is sold or used by another operator, it should be in working condition and include this operator's manual. In case of loss or destruction of the operator's manual, a new copy should be purchased by ordering at the dealer.



NOTICE!

The manufacturer is not liable for accidents caused by none compliance with safety rules.



NOTICE!

Before operating, repair work or mower regulation, turn off the PTO, lower machine on the ground, turn off the tractor engine and remove the key from the ignition and disconnect PTO shaft of the tractor. The whole set: the mower and tractor must be secured against undesirable moving.



NOTICE!

Read this instruction manual carefully before operating the mower. Otherwise it is forbidden to operate the machine. This applies to unauthorized personnel, children in particular.

2.1. Safety rules

Operator:

1. The mower for mowing short stem plants and roadsides can be operated only by adults familiar with the contents of the operator's manual and the general safety rules.
2. Read this instruction manual carefully before the first starting up the mower and after a long stoppage.
3. Only adults (over 18) authorized to operate the tractor can operate the mower.
4. Operation of the machine by minors and persons who are under the influence of alcohol or drugs is forbidden.
5. Personnel operating the machine should be trained on health and safety regulations, fire protection and have the clothing and footwear and personal protective equipment appropriate to the existing threats.

Before starting

1. The mower's condition should be carefully checked before each use, especially the state of knives wear, their self-fixing, the state of covers and hydraulic hoses and the correctness of attachment to the tractor.
2. The operator must make sure that within the mower operation range there are no individuals (children in particular) or animals before starting and during the mower operation.
3. Before starting the tractor unit, make sure that you know how to stop the tractor in the event of emergency.
4. Before starting the PTO of the tractor, make sure if there are no individuals nearby or left parts or tools on the machine.
5. PTO shaft can be put on and taken off after turning off the drive shaft PTO tractor, turning off the engine and removing the key from the ignition.
6. No one is allowed near the rotating shaft before connecting PTO shaft and also during its work.
7. Use the PTO shafts marked with CE and the shields in good stock accepted by the manufacturer.

Aggregating

1. The tractors with adequate power and categories suspension should be used to cooperate with the machine.
2. The operator of the tractor is responsible for the security of the tractor- mower against accidental operation by unauthorized persons, children in particular.
3. Before connecting the mower to the tractor, check if it is standing on a level, hard surface. Do not aggregate when the tractor is on the sopping place.

Operation

1. Do not operate the mower on slopes exceeding 8.5 °.
2. Never stand between the tractor and the machine during the tractor's engine operation. Never start the mower if persons or animals are present around the machine.
3. Never get onto the machine or onto other parts of the machine during operation. Never place any parts on the machine for further transportation, it can be additional loading during its working time.
4. The working area must be secured against bystanders' accidental approach.
5. No one is allowed to get onto the machine and remain on the machine during its operation.
6. The acoustic tractor signal should signal that the drive drum operation is switched on.
7. Never leave tractor's engine running without supervision. Before you leave the tractor, disconnect PTO, stop the machine, leave the machine and immobilize the tractor and turn off the engine and remove the key from tractor's ignition.
8. Do not control tractor's lever hydraulic lift from the outside of it.
9. Be particularly careful when controlling tractor hydraulic lift positioned outside the cab.
10. Be particularly careful when mounting and dismounting the mower.
11. Leave the machine on the ground and turn the engine off, remove the key from tractor's ignition during each break in the work.
12. The mower should be cleaned after each finished operation.
13. Hazardous places are marked on the machine with yellow warning pictograms. The meaning of each sign is stated in the "Pictograms warning." Check out the meaning of each sign. Pay particular attention to such marked places on the mower during operation.

PTO

1. When starting the engine of the tractor, drive PTO and hydraulics external must be turned off.
2. Verify that the covers of PTO shaft do not rotate with the shaft. Attach carefully the chain arrest.
3. The speed of rotation of the tractor PTO must correspond to the use of the machine.
4. Drive PTO must be switched off when it is not needed and when tractor with the machine is on too big inclination.
5. Be aware of overlapping shields PTO shaft with cover WPM and PTO both during the transportation and working position. Overlay covers should be min. 50 mm.
6. After putting the PTO shaft on the tip of the tractor PTO, its locking pin must be located in the shaft groove. Make sure that the shaft is well founded.
7. After removing the PTO shaft from the tractor, it should be attached to the provided holder.

Transport

1. Never transport persons on the mower or tractor (except the places intended for this use) both during operation and during moving.
2. Take particular care during transport from the farm to the workplace.
3. Never move the tractor mower unit on public roads.

Repair

1. Do not repair the machine when bystanders, children in particular remain.
2. In the event of injury, the wound should be immediately washed and disinfected with hydrogen peroxide, because contamination can cause wound infections posing a risk to human health and life.
3. Before performing any service or maintenance on the mower, at first disengage the PTO , turn off the tractor engine and remove the key from the ignition and disconnect articulated telescopic shaft of the tractor.
4. Worn or damaged components of working mechanical team, should immediately be replaced with the new original parts.
5. In the event of damage or wear, the shields must be replaced.

Storage

1. Put the machine on a flat, hard surface.
2. Do not leave the mower raised on a hydraulic lift of the tractor.
3. Only common screws, cotter pins, bolts, cotter pins must be used to secure the position of the working units and connecting components.

2.2. Fire regulations

1. The fire-fighting equipment should be the equipment of the tractor cabin (ABC fire extinguisher).
2. Do not smoke and use of open flames near the working machine.
3. Remove all residual material that could cause a fire from the machine before starting repairs, welding works in particular. Before starting the welding work, disconnect the battery of the tractor, electrical wires and hydraulic equipment must be protected from damage.



Remember that the requirements for health and safety work and fire regulations must be strictly respected!

3. DESCRIPTION OF RESIDUAL RISK

The mower for mowing short stem plants and roadsides was manufactured using all rules to ensure its safe operation. This does not exempt operator from the special care and safety rules under the other rules and principles.

The greatest risk arises through the presence of persons, children in particular and animals within the mower operation range. Major source of risks arises when paying insufficient attention to the warning labels!

Major source of risk follows performance of these operations:

- presence of persons, children in particular within the mower operation range,
- performing maintenance when mower's working element is operating,
- performing maintenance when the tractor's engine is on,
- standing between the machine and the tractor when the engine is on,
- using of the mower for purposes other than described in the manual,
- performing adjustments within the mowers suspension system,
- using unsecured PTO shafts. When respecting the instructions of operator's manual and safety rules, the occurrence of hazards will be minimized !

The assessment of residual risk during operation

The following rules are to be observed:

- read this instruction manual carefully before operating the mower,
- do not allow children to be near the operating machine,
- use the machine only for its intended purpose,
- wear protective clothing free of loose parts,
- only the operator can operate the machine (read the instruction manual and safety regulations carefully), inspections and repairs are done by a trained person,
- the machine during repairs and daily maintenance which exclude threat for the user.

When respecting the instructions of operator's manual and safety rules, the residual risk can be minimized!



NOTICE!

























Residual risk is present if not respecting the descriptions of specified instructions and forbidden actions.

4. WARNING PICTOGRAMS

Particularly dangerous places are marked with yellow pictograms, white warning and information signs on the machine.

Read the descriptions of the signs carefully and respect these instructions strictly. During the operation special attention and caution should be paid when being directly close to the indicated places on the machine.



The meanings of pictograms on the machine are shown below:

- | | | | | | |
|----|---|---|----|---|---|
| 1 |  | Keep a safe distance from the machine - flying out hard objects | 13 |  | Keep a safe distance when leaving the mowers team |
| 2 |  | Read the operator's manual | 14 |  | Beware of the drive transfer system - the risk of being pulled-in |
| 3 |  | Do not occupy space area of articulated connections while changing the mower's position | 15 |  | Do not reach into the area of crushing, the parts can move |
| 4 |  | Being on the machine while operating is forbidden | 16 |  | Keep a safe distance from the machine because of the danger of toes or feet crush |
| 5 |  | Do not occupy the space between tractor and the engine during operation of the tractor | 17 |  | The direction and magnitude of rotation of PTO |
| 6 |  | Turn off the engine and remove the key before starting maintenance or repair operations | 18 |  | While transporting hydraulic shut-off valve must be closed |
| 7 |  | Do not touch the machine parts before all the teams does not stop working | 19 |  | Do not operate when any person remains in the danger area of 50m |
| 8 |  | Do not open or remove safety guards, if the engine is operating | 20 |  | Do not drive on public roads |
| 9 |  | Keep a safe distance zone blade mowers, if the tractor engine is working and WPT is on | 21 |  | Oil filling point |
| 10 |  | Risk of injury by hydraulic oil under high pressure | 22 |  | The pressure of the hydraulic system |
| 11 |  | Adjusting belt tension gear maintain according to the instruction manual | 23 |  | |
| 12 |  | Lubrication points | 24 |  | The points of attachment of raising devices |



NOTICE!

Keep all warning labels clean and legible! Replace all lost or damaged labels by ordering new ones from your dealer or supplier. New labels can also be ordered from manufacturer.







Fig. 2. Placement warning pictograms on the mower KS, KSP, KSHP (designation of signs according to p. 4)








Fig. 3. Placement warning pictograms on the mower KM, KMH, KMH Profi (designation of signs according to p. 4)






Fig. 4. Placement warning pictograms on the mower KDX, KDX Profi (designation of signs according to p. 4)

5. GENERAL INFORMATION

5.1. Introduction

Read this instruction manual and safety rules carefully before operating the mower.

Read the terms of the proper and safe operation.

Manufacturer UAB "AGROTEKAS" reserves the right to make - in the framework of the modernization product - design changes that do not affect its functionality each time without manual adjustments.

The manufacturer does not allow arbitrary changes in construction. Possible proposal for changes and improvements must be reported and agreed with the company UAB "AGROTEKAS" or the manufacturer's service.

The changes made without consulting the manufacturer absolve the consequences of their introduction void the warranty.

Maintenance and operation of the mower inconsistent with the instructions absolves the manufacturer from liability for the consequences of improper use and will void the warranty. If in doubt about using your mower, please contact the dealer or the manufacturer service asking for detailed explanation.

5.2. Design of the mower

Flail mower comprises (Fig. 3) :

- three-point linkage suspension system (1),
- load-bearing body (2),
- drive system of cutting elements,
- front split cover (3).




Fig. 5. Parts of flail mower KS, KS Profi, KSH Profi
 (1 – three-point linkage suspension system, 2 - load-bearing body, 3 - front split cover, 4 – intersecting axis gear, 5 – intermediate pinion, 6 - belt gear, 7 - skid, 8 – support).






Fig. 6. Parts of flail mower KM, KMH, KMH Profi
 (1 – three-point linkage suspension system, 2 - load-bearing body, 3 - front split cover, 4 – intersecting axis gear, 5 – intermediate pinion, 6 - belt gear, 7 - skid, 8 – support).




Fig. 7. Parts of flail mower KDX, KDX Profi
 (1 – three-point linkage suspension system, 2 - load-bearing body, 3 - front split cover, 4 – intersecting axis gear, 5 – intermediate pinion, 6 - belt gear, 7 – skid).

Mower KS, KS Profi, KSH Profi, KM and KMH is aggregated on the rear three-point linkage tractor. Mower KDX, KDX Profi, KMH Profi aggregated on the linkage tractor both in the front and rear. The flail drum is driven by the tractor's PTO shaft, WPM on the machine, intersecting axis gear (4), intermediate pinion (5), belt gear (6). On the drum there are mounted flail blades. The number of blades on the drum is depended on working width of the mower. The cutting height is regulated by changing the position of the ground following bar. At the side of mowers there are skids (7). In the front of mower there is a split cover (3) and the support (8). In flail mowers KDX, KDX Profi, KMH, KMH Profi and KSH Profi lateral adjustment is achieved by a hydraulic system.

5.3. Delivery and receipt of the mower

The manufacturer delivers a complete machine.

To prevent the mower from displacement or turning, secure during transport on the vehicle trailer.

The driver and the carrier are responsible for the mower's transport safety. Equipment and parts must be secured during transport. Some parts of the mower can be used for installing the sling. These places are marked with pictograms. For mower lifting, use only lifting devices with hoisting capacity larger than mower's weight shown in data plate.



NOTICE!

Unloading mower can be done with the help of such devices: forklift, crane runway or crane grabbing the mower at the points marked with the appropriate sign.

When moving the mower to another means of transport, the presence of other persons in the moving operation area is forbidden. There is a risk of stroke or crushing of the human body.

6. SAFE OPERATION RULES



NOTICE!

To work with the mower should be used tractor with adequate power and the category of the suspension.



NOTICE!

When mounting the mower, all precautions must be taken. Use only original screws, pins and cotter pins for fixing the working units.

6.1. Preparing the tractor for operating the mower

The tractor to work with the mower should be in a technically working condition. Before attachment the mower to the rear three-point linkage tractor, read the instruction manual of the tractor, particularly the section on the suspension of the tool.

6.2. Preparing the mower for operation



NOTICE!

Read this instruction manual and work safety rules carefully before operating the mower. Read the instruction manual again when the machine has not been used for a long time.

Preparing the mower to work, refer to the instructions contained in manual section 9 "Storage".

The mower is delivered complete and ready for use. The representatives of the manufacturer or service agent is not required for the first start up.

Before starting the mower, check flail blades and fasteners. Replace damaged parts.

In order to attach the mower KS, KM, KMH, KMH Profi, KDX, KDX Profi and KS Profi, KSH Profi to the rear three-point linkage tractor you should:

- drive the tractor to the mower, connect the joints of the lower arms of the tractor with the pivots suspension and secure cotters,
- connect the upper connector to the upper suspension point by means of a pin and cotter,
- adjust the length of the top link so that the runners are parallel to the substrate,
- raise the mower using hydraulic lift of the tractor,
- submit a support and a cotter pin.

In order to attach the mower KS, KM, KMH, KMH Profi, KDX, KDX Profi and KS Profi, KSH Profi to the rear three-point linkage tractor you should:

- move the bolts of lower pins and upper pin,
- move the plastic cover of PTO,
- drive the tractor to the mower, connect the joints of the lower arms of the tractor with the pivots suspension and secure cotters,
- the upper connector to the upper suspension point by means of a pin and cotter,

- adjust the length of the top link so that the runners are parallel to the ground,
- combine hydraulic hoses of the mower with the plugs of external hydraulic hoses of the tractor,
- raise the mower using hydraulic lift of the tractor,
- submit a support and a cotter pin.

IMPORTANT !

The attachment of the machine to the tractor can influence the handling of the tractor. After the mower has been attached to tractor, check balance and steer ability of tractor-mower set. To do it, weigh the set and after that drive on the scales with only front axis of the tractor (the mower must be in transport position – lifted upwards). If the pressure on the front axis is at least 20% of the total tractor mass (without machine), it means the set is stable. If not, front axis should be balanced.

To detach the mower from the tractor, perform the same steps in reverse sequence. Raising and lowering the mower by tractor hydraulic lift should be done gently without jerking.

Refer to the instruction manual of the tractor if the tractor's hydraulic lift capacity is sufficient to raise the mower. After lifting the lowest situated parts of the machine should be kept transport clearance, a minimum of 25 cm.

6.3. Adjusting mowing height

The mower is adapted to operate in the normal position of the cutting height equal to 30 mm. Shaft copying screws and side skids (KS, KM, KMH, KMH Profi, KDX, KDX Profi and KS Profi, KSH Profi) are used to adjust the cutting height. To adjust cutting height, release screw (1) and unscrew screws (2) on both sides (Fig.6). Unscrew screws (3) on both sides to adjust the position of the runners. Adjust the height of the shaft copying. Stiff the parts in the set position. Setting in a lower opening will allow the maximum cutting height. Tighten the screws (2) on selected holes. Fasten the screws (1) and (2).




Fig. 6. Adjusting mowing height

6.4. Operation



NOTICE!

When the drive is turned off and all the moving parts are stopped, you can clean the mower manually. Otherwise, there is a risk of injury.

When moving the mower to the working position, special caution must be taken. There is the risk of hit or crushing.

When operating the mower tilting, removal and attachment of the covers or other security guards are unacceptable.

At the work place:

- make a general review of the machine,
- check fastening flail knives,
- mount articulated telescopic shaft connecting the tractor PTO with WPM machine,
- not start the PTO if any persons remain near the machine or any left parts or tools are on the machine,
- start the PTO at engine idle speed of the tractor,
- increase the PTO speed of the tractor. When operating, observe the speed which should be 540 rpm,
- in the tractor instruction manual check engine speed at which the PTO may achieve the required number of rotations.



NOTICE!

Use only PTO shafts specified by the mowers manufacturer.

If needed, shorten shaft according to the instruction manual indicated by shaft manufacturer.

PTO shafts are attached to the end of the spline WPM mower and PTO tractor. Paying attention to the outer tube of the shaft covers is placed from the tractor side. The cover of the shaft must be secured against turning by hooking chain retaining a constant point of the tractor body and the mower.



NOTICE!

PTO shaft should only be installed during the mowers working time. During transport and in the performance of any work maintenance, PTO shaft should be disconnected from PTO tractor.

Never start the PTO shaft if the tractor engine is off.

When operating, it is forbidden to remain near rotating PTO and PTO shaft.

Always turn off the PTO shaft when there is too much banking angle of the PTO shaft, and when there is no need to use it.

**NOTICE!**

Immediately after switching off the PTO shaft drive, there is a danger of rotating masses. At this time, do not approach the mower until it completely stops.

Before starting work, make a test drive to determine the best parameters operation. Choose the operating speed depending on local conditions and the type of workpiece, so that not to load the machine and prevent it from clogging. When turning on the flail shaft drive, lead to a whole number of rotations before the machine enters into mowed material. The speed should be adjusted depending on the terrain and the kind of mowing material, because improper selection of operating parameters of the mower can lead to the blockages or damage of the machine. Flail mower should not be operated on uneven and stony ground. The blades of equal length and weight must be mounted to the flail drum, otherwise the imbalance will cause damage to the mower.

**NOTICE!**

Before entering into the workpiece, the machine has to be at full rotation. Starting the machine under load is prohibited. When working, do not reduce the number of rotations.

In order to unblock the machine or fix the failure, turn off drive PTO shaft, turn off flail shaft, stop the tractor then retreat to the back, turn off the tractor engine, take ignition key off, unblock or remove the failure. Then insert the key into the ignition, start the engine of the tractor, drive in this position a few meters forward and then proceed to work by following the same steps in reverse order.

When entering the obstacle, there is always the danger that damaged machine can cause dangerous situations. For this reason, you must always keep safe distance.

Normal usage of the machine is not dangerous if it is carefully controlled and maintained and it has not been previously damaged.

In order not to increase the consumption of parts, observe the following guidelines:

- clean the entire machine from sediment pollution after everyday use,
- check the technical state of the machine and replace defective parts.

**NOTICE!**

If vibration occurs, stop the machine and check the flail knives. When the knife is destroyed or damaged, replace it with a new one of the same size. If vibration persists, the mower should be delivered to an authorized service center for repair.

6.5. Moving from transport to working position

In order to move the mower from the transport position to operating position:

- make sure, if the ground is even and stable and there are no unauthorized persons,
- open hydraulic valves,
- leave the mower on the ground,
- set the mower in an appropriate transverse position.

To convert the mower from the working position to transport position, described steps should be performed in reverse order.

6.6. Moving KMH, KMH Profi, KDX, KDX Profi and KSH Profi from central to side position

KMH, KMH Profi, KDX, KDX Profi and KSH Profi flail mower is equipped with a hydraulic change lateral settings of the mower. To change the lateral mower settings, move the lever appropriate hydraulic valve on the tractor and release it when you get desired shift of the mower to the left or right. Lateral mower settings regulation should only be made when you lift it on three-point in the transport position, and after stopping the PTO and the slowdown mower flail shaft. To transport the mower, it must be set in central position and the cutting unit must be raised.

6.7. Replacement of flail knives



NOTICE!

Check periodically the condition of flail knives. Damaged or worn out flail knives must be replaced with new ones. There is a risk of ejection of a broken flail knife which is a threat to life and health of the operator and bystanders.

All flail knives must be of the same type and have the same mass. If necessary, they should be replaced with new ones. Due to the shaft balance, a couple of flail knives should always be exchanged, i.e. two knives lying on opposite sides of the shaft in the coming himself planes. The flail knives can be obtained from the mowers manufacturer - UAB "AGROTEKAS".



NOTICE!

Check periodically the condition of flail knives holders. Damaged or worn out flail knives holders must be replaced with new ones. There is a risk of ejection of a broken flail knife which is a threat to life and health of the operator and bystanders.

6.8. Travelling on public roads

You must be particularly careful and adjust the travel speed to the conditions of travel when travelling from the farm to the place of work. Travel only on non-public roads. Transporting the mower to the workplace must be done only on the other means of transport.

When moving the whole machine unit with the tractor, the support must be lifted and secured in this position.

Any changes in the position of the mower can be performed if there are no bystanders, children in particular.



NOTICE!

Flail mower KS, KM, KMH, KMH Profi, KDX, KDX Profi and KS Profi, KSH Profi is not approved for travelling on public roads. It is marked with the appropriate sign on the machine (the sign is below).



7. MAINTENANCE SERVICE



NOTICE!

All maintenance operations should be carried out on a flat, paved area after securing the tractor against rolling and against possibly starting by unauthorized persons.



NOTICE!

Before any maintenance, repair or regulations of the machine, turn off the PTO, lower machine on the ground, switch off the engine and remove the key from the ignition and disconnect the PTO shaft. The whole set of the tractor and the machine must be secured against unintentional rolling of the machine. It is forbidden to enter the mower suspended on three-point system suspension of the tractor.

IMPORTANT!

Any regulation work and maintenance should be performed with caution, to avoid crushing or injury of the operator's hands. The operator should use right keys and protective gloves. Wear safety glasses when maintaining hydraulic handling.

NOTICE!

1. Repairing, cleaning, lubrication, checking the technical condition must be done only when the machine is lowered, the PTO is turned off, the engine is turned off and the key from the ignition is removed or when the mower is disconnected from the tractor and securely supported in the rest position.
2. Fasteners such as nuts and bolts are regularly checked and possibly tightened. To exchange use the proper tools.
3. When carrying out repairs only original spare parts according to the technical conditions of the manufacturer must be used.
4. When carrying out welding operations, disconnect the battery and the generator (on the tractor) if it is attached to the machine.
5. It is forbidden to carry out repairs under the lifted and unsecured against accidental falling down of the machine. If you need to repair, the lifted machine should be secured with a durable and stable support, e. g. wooden blocks. Inappropriate security of the machine can cause serious accident.

DAILY MAINTENANCE

When you finish each day of operation, clean thoroughly from the remains of plant and other impurities, review of bolted and dowel connections and the state of the individual parts.

Damaged or worn parts must be replaced. All loose screw connections should be tightened, damaged cotters and cotter pin should be replaced with new ones.

Check the condition of flails, and if it is a need, replace set of two flails.

All repairs and replacement of parts of the mowers drive must be made by a specialist company, equipped with the right equipment and tools.

SEASONAL MAINTENANCE

After the end of mowing season, the mower should be thoroughly cleaned, damaged work surface paintings should be washed with kerosene and protect against corrosion with a thin film of a solid grease. Moreover,

- out a full lubrication of the machine,
- when changing the oil in the gearbox is recommended to pay special attention to correct position of the rubber seal. Proper screw cap. The failure of this can result in unnecessary leakage of oil from the gearbox. In case of doubt to the quality of the seal, it is recommended to replace it,
- oil level in the angular gearbox should reach the check hole. In case of low oil level, it should be topped up. The oil level can vary between 1.5 and 3 cm. The main gearbox of the mower, there should be 0.85 liters of transmission oil of high viscosity, e. g. N46.
- while not operating the machine, store it under a roof. If there is not such a possibility, you should periodically check the condition of security and, if necessary, replenish grease washed off by rain.

After three seasons of flail mower use, the oil in the transmission angle should be exchanged. Exchange should be carried out when the PTO and engine are off and the ignition key is removed:

- unscrew the cap on top of the control gear,
- check the oil level,
- in case of a small amount of oil, top up until it is visible in the check opening.
- Check the oil level when the machine is horizontally onto the ground.

The basic maintenance must comply with lubrication intervals. Lubricated points should be lubricated 3-5 times with a lubricating gun. For the lubrication of the machine use only solid mineral lubricants. Before pressing or applying grease, lubrication points and lubrication nipple should be cleaned and removed from mud. Immediately replace or repair damaged lubrication point.

Lubrication points are marked with the appropriate sign.

IMPORTANT!

Periodic lubrication guarantees a long service life.

Carry out lubrication only when the tractor is switched off and the key from ignition is removed.

Secure the tractor and the mower against rolling.

NOTICE!

Obey absolutely lubrication frequency of the PTO. Points indicated by the manufacturer of the shaft should be lubricated every 50 hours. Lubricate well before and after a long standstill of the PTO.

7.1. Regulation V-belts tension

Remove the cover belt transmission. Loosen the screw. Adjust driving belt tension with a screw at point B until the bar reaches the required tension (Fig. 7). Tightening the screw, tightens the belt. After the adjustment, tighten all screws. Reinstall the cover of the V-belt. Adjust the automatic belt tension using three-way handle C until the belt reaches the required tension.




Fig. 7. Regulation V-belts tension

8. HYDRAULIC SYSTEM

Mower KMH KMH Profi, KDX, KDX Profi and KSH Profi is equipped with a hydraulic system intended for moving to the working position of the mower.

Before operating the mower, check the condition of the pipes and hydraulic connections. Remove leaks tightening the connection.



NOTICE!

Worn and leaky hydraulic lines such as leakage of fluid under high pressure may cause a threat to operating persons. A danger of environmental pollution in case of the possible oil spill. Hydraulic hoses should be replaced every five years, taking into account the period of storage.

Use hydraulic oil based on mineral oils for the flail mower. While replacing, take into account the type of oil. The use of other hydraulic oil than recommended can damage hydraulic mower or combined vehicle.

To change the position of the mower, a hydraulic cylinder is used. In case of lack of action, the control should be carried out at a qualified repair service. The control of the cylinder is done by means of a tractor control devices.

Carry out all adjustments and repairs when there is no pressure in the hydraulic system.




Fig. 8. Scheme of hydraulic system of flail mower KMH, KMH Profi, KDX, KDX Profi and KSH Profi:

1 - hydraulic hoses, 2 – hydraulic ram, 3 - hydraulic shut-off valve

After disconnecting the hydraulic hoses from the tractor, attach it in the holder located on the machine.

9. STORAGE



Store the mower firmly resting on a flat surface to prevent accidental mutilation of people or animals. Store it under the roof.

9.1. Preparing mower for storage

IMPORTANT!

When you finish each day of operation, thoroughly clean up impurities and check mower's condition.

Before starting operation after it has not been used for a long time:

- carefully clean the machine from dirt,
- carry out technical control, remove noticed faults,
- clean, remove rust then cover with the primer and enamel topcoat the places of damaged paints,
- replace worn or damaged parts.

The mower should be stored in covered places to prevent mutilation of humans or animals. Before lowering the machine on the ground, pull out the support placed in front the mower. After lowering the mower on the ground, disconnect top link, the lower rod of suspension pins, hydraulic hoses connectors, PTO shaft and slowly drive the tractor. When the machine is disconnected from the tractor, it should be supported on the support, on firm flat ground, striking the sustainable balance.

Store PTO shaft on a special stand. Check the condition of the mower, cables and hydraulic connections. Remove leaks by tightening the connection.

9.2. Starting up the mower after storage period



NOTICE!

A danger of environmental pollution in case of the possible oil spill.

To start up the mower after storage period do the following:

- grease mowers lubrication points,
- grease the telescopic tubes of PTO shaft with grease,
- grease both sides of the bearing flail shaft,
- check the chest angle and remove any spills,
- perform the operations described in points 6.1 and 6.2 of the manual.

Check the oil level and, if needed, refill after having removed the vent on the top of the gear. The oil level can be checked through check opening on the side of the gearbox. Please refill the oil until it is visible in the check opening. The oil capacity: about 0.85 l. Check oil level when the machine is on the ground.

10. LOCATION AND IDENTIFICATION OF MOWER MALFUNCTIONS

Tab. 2. Identification of mower malfunctions

Defect	Possible reason	Recommendations
Mower stops mowing	Decline of flail knives	Insert new flail knives
	Worn flail knives	Replace worn flail knives to new ones
	Flail knives improperly attached	Attach flail knives in accordance with recommendations in the operator's manual
	Polluted space between flail knives and knives holders with mud, remnants of grass, etc.	Remove impurities (remove with high-pressure water)
	Transmission belts sliding	Worn V-belts replace with new ones
	Damaged PTO of the tractor, do not transmit rotations	Remove defected PTO in service station
	Stones between movable parts	Stop and remove stones
Excessive vibration during operation	Laying grass	Low mowing
	PTO is bent	Check the state of PTO and, if needed, replace it
Oil spill in gearbox	Damaged flail knife	Replace flail knife
	Unsealing system	Check seal and oil level
Or in cylinder	Loose hydraulic hoses	Fasten hoses. Check seals, if needed, replace
	Dirty hydraulic oil	Replace hydraulic oil
KDX, KDX Profi, KMH, KMH Profi, KSH Profi mower does not move	Not calibrated or damaged hydraulic system	Adjust throttle valve
		Check the state of hydraulic hoses. If needed, replace them

After removing all malfunctions, do a test run of the unloaded machine and check the proper operation of all mower teams.

11. WITHDRAWAL OF MOWER FROM USE

The last user or person/company, who owns the machine at the time when it is withdrawn, is responsible for withdrawal of the mower from use.

Withdrawal of mower from use and liquidation of all kinds of waste thereby created must be carried out in accordance with the law of the country where the machine is used.



Precautions shall be taken when dismantling of mower, in particular, when disconnecting teams and parts. Scrapping disassembled parts should meet the requirements of environmental protection.

Most of the parts are made of not decaying materials, therefore the machine must be scrapped in parts and various kinds of material handled in accordance with national legislation:

1. Steel and other metals are delivered to scrap yards.
2. Materials and rubber parts are delivered to a proper waste treatment company for reuse or scrapped in any other manner in accordance with national legislation.
3. Used hydraulic oil should be drained and delivered to a proper waste treatment company.

For more information on the machine dismantling and waste handling please contact the institutions involved in environmental protection.

Dismantling of the machine should be done wearing protective gloves.

12. WARRANTY CLAIM PROCEDURES

- ❖ The user shall mean the natural or legal person purchasing the mower, the dealer - commercial unit providing the user equipment and the manufacturer - manufacturer of agricultural equipment.
- ❖ Under the warranty the manufacturer or authorized unit in case of approved warranty claim is obliged to:
 - the free repair of faulty machine,
 - to supply free of charge new properly manufactured parts.
- ❖ A 12-month warranty is granted on the machine from the date of purchase.
- ❖ The basis for the settlement of the warranty claim within the warranty period is the complaint coupon with stated date of purchase of the machine. It should be done no later than 14 days from the date of occurred failure.
- ❖ Warranty repair is deemed reasonable and related to the warranty period should be made immediately. But no later than within 14 days from the time when the machine is applied and physically accessed for repair, unless the user expressed written consent for the period extension.
- ❖ If the dealer has not delivered operator's manual or warranty card or misused its fulfilment, he is responsible for any additional costs to which a user was exposed during the warranty period.
- ❖ Warranty card which has been attached to the sale concerns only this equipment.
- ❖ If warranty service is made on behalf of the manufacturer authorized representative, the dealer is obliged to enter the address of this representative on the warranty card.
- ❖ On behalf of the manufacturer the repair shops which have been authorized for warranty repairs may process warranty claims. The user can submit a complaint directly to the manufacturer or dealer.
- ❖ If you believe that the negatively settlement of notified warranty claim is right, you may request the dealer to reconsider the claim.
- ❖ The user entitled to warranty service has the right to exchange the machine for a new one in case of failure of three of the same material or component parts.
- ❖ The warranty does not cover those parts listed in the manual subject to normal physical wear as a result of the work which took place before the expiry of the warranty period.
- ❖ The warranty is extended for the period in which the equipment was repaired.
- ❖ The user loses warranty in the following cases:
 - damage to the machine due to the random cases or traffic collisions independently of the quality and technical efficiency of the machine,
 - modifications and changes of its mechanical design without the written consent of the manufacturer,
 - lack of proper care and maintenance of the machine and use of the machine not in accordance with the operator's manual or for incorrect purpose as well as operating with no legal components,
 - if the damaged equipment is not presented for inspection before repair,
 - repairs carried out by not authorized dealer's service and using for repairs not original manufacturer's replacement parts of mowers,
 - preventing repair by the user or the consideration of claim legitimacy.

WARRANTY CARD

(send to manufacturer)

Flail mower

Type/model..... serial number year of manufacture

Date of purchase (in words)

Warranty is valid for 12 months from the date of purchase. carries out the service on behalf of the manufacturer.

.....

(fields are completed by dealer)

.....

(dealer's signature and stamp)

Warranty card is required for all warranty claims

stamp of sales centre

Complaint coupon No 2

Flail mower

Serial number

Report of complaint No

Warranty prolonged

.....

Date of purchase

I received machine in proper working condition after repair

date:

.....

(user's signature)

stamp of sales centre

Complaint coupon No 1

Flail mower

Serial number

Report of complaint No

Warranty prolonged

.....

Date of purchase

I received machine in proper working condition after repair

date:

.....

(user's signature)

THE HANDING-OVER REPORT OF THE MACHINE

The report is an integral part of the warranty card


The report without correct information or illegible information is invalid! The signing parties (dealer and purchaser) of this report hereby declare:

- The machine is delivered to the purchaser fully assembled and ready to work.
- The purchaser has been informed by the dealer about the proper handling of the machine, its operation and maintenance. As well as about the applicable health and safety at work regulations in accordance to the operator's manual which has been given to the purchaser.
- The user has been informed about warranty terms.
- The purchaser acknowledges receipt of the operator's manual.

DEALER	PURCHASER
FAMILY NAME	FAMILY NAME
STREET	STREET
TOWN	TOWN
SIGNATURE AND DATE	SIGNATURE AND DATE

**SELLER SHALL RETAIN THE LEGIBLY SIGNED HANDING-OVER
REPORT OF THE MACHINE**

ASSEMBLY DRAWING LIST




KDX three-point linkage

Ser.No	Code	Name & Specification	Quantity	Remarks
1	B000040	Bolt M16×100	4	KDX
2	W000012	Big washer M16	8	KDX
3	N000033	Lock nut M16	4	KDL, KDLP, KDX, KDXP, KM, KMHP, KSP
4	N000030	Lock nut M10	4	KDL, KDLP, KDS, KMHP, KDX, KDXP, KS, RS, KSP
5	W000014	Washer M10	8	KDL, KDLP, KDS, KMHP, KDX, KDXP, KS, RS, KSP
6	B000023	Bolt M10×80	4	KDX180-200
	B000016	Bolt M10×110	4	KDX220-240, KDXP180-240
7	400008	Suspension plate	4	KDX
8	400009	Connecting square tube	1	KDX
9	400010	Front riser Linkage	1	KDX180-200
	400011	Front riser Linkage	1	KDX220-240
10	400012	Round pipe plug	4	KDX220-240

KDX three-point linkage

Ser.No	Code	Name & Specification	Quantity	Remarks
11	S000015	Circlip for hole 45	4	KDX180-200, KMH, KMHP, KSHP
	S000016	Circlip for hole 65	4	KDX220-240, KDXP180-240
12	200023	Self-lubricating bearing 40×44×50	4	KDX180-200, KDL, KDLP, KMH, KMHP, KSHP
	400016	Self-lubricating bearing 60×65×50	4	KDX220-240, KDXP180-240
13	200004	Quick connector cover	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
14	200005	Hose Quick connector G1/2	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
15	200006	Combination washer G1/2	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
16	400020	Slide pipe	2	KDX180-200
	400021	Slide pipe	2	KDX220-240, KDXP180-240
17	200010	Hose 1900 mm	1	KMH, KMHP, KDX, KDXP, KSHP
18	200007	Hose 1500 mm	1	KMH, KMHP, KDX, KDXP, KSHP
19	200008	Hollow bolt	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
20	200009	Combination washer 12	4	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, RS, KSHP
21	N000018	Thin nut M18×1.5	2	KMH, KMHP, KDX, KDXP, KSHP
22	200014	Hydraulic cylinder	1	KDX180-200, KMH, KMHP
	400028	Hydraulic cylinder	1	KDX220-240, KDXP180-240
23	200013	Cylinder sleeve	1	KMH, KMHP, KDX, KDXP, KSHP
24	W000005	Spring washer M18	1	KMH, KMHP, KDX, KDXP, KSHP
25	N000012	Nut M18×1.5	1	KMH, KMHP, KDX, KDXP, KSHP
26	100003	Lock pin	3	KDL, KDLP, KDX, KDXP, KM, KMHP
27	400033	Lower linkage pin	2	KDX
28	400034	Lock pin 4.5	2	KDLP, KDX, KDXP
29	400035	Rear riser Linkage	1	KDX180-200
	400036	Rear riser Linkage	1	KDX220-240
30	100002	Hook	1	KDL, KDLP, KDS, KDX, KDXP, KM, KMHP, KSP
31	400038	Upper linkage pin	1	KDL, KDX, KDXP

ASSEMBLY DRAWING LIST



KDX series

Ser.No	Code	Name & Specification	Quantity	Remarks
1	W000010	Big washer M12	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KSP
2	W000002	Spring washer M12	10	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, RS
3	B000084	Bolt M12x30	8	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, RS
4	400042	Gearbox	1	KMHP, KDX, KDXP
5	K000009	Key A10x65	1	KM, KMHP, KDX, KDXP
6	400044	Shaft protection	1	KMHP, KDX, KDXP
7	B000073	Bolt M10x16	8	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP
8	W000001	Spring washer M10	8	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
9	W000014	Washer M10	4	KDL, KDLP, KDS, KMHP, KDX, KDXP, KS, RS, KSP
10	K000001	Key A10x40	1	KM, KMHP, KDX, KDXP
11	400249	Drive shaft for 180	1	KDX180
	400049	Drive shaft for 200/220	1	KDX200-220, KDXP200-220
	400050	Drive shaft for 240	1	KDX240, KDXP240


KDX series

Ser.No	Code	Name & Specification	Quantity	Remarks
12	100060	Drive shaft tube	1	KM, KMHP, KDX, KDXP
13	W000009	Big washer M10	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, KSP
14	000024	PTO protection	1	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KSP
15	000030	Gearbox shaft cover	1	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, KSP
16	400055	(Right) Roller protect	1	KDL, KDX
17	600078	Grease Nipples M10	3	KDL, KDLP, KDX, KDXP, KMHP, RS
18	500043	Hanging plate (Right)	1	KDL, KDX
19	S000010	Circlip for hole 90	4	KDL, KDLP, KDX, KDXP
20	B000103	Bolt M16×45	4	KDL, KDX, KDXP
21	W000017	Washer M16	8	KDL, KDLP, KDX, KDXP
22	N000033	Lock nut M16	4	KDL, KDLP, KDX, KDXP, KM, KMHP, KSP
23	OS000008	Oil seal 45×90×10	2	KDL, KDLP, KDX, KDXP
24	400063	Bearing 6308-RZ	4	KDL, KDLP, KDX, KDXP
25	100030	Paper washer	1	KM, KMHP, KDX, KDXP
26	B000146	Hex cylinder head screw M12×35	4	KM, KMHP, KDX, KDXP
27	400266	Drive shaft tube for 180		KDX180
	400066	Drive shaft tube for 200/220	1	KDX200-220, KDXP200-220
	400067	Drive shaft tube for 240	1	KDX240, KDXP240
28	B000130	Bolt M16×1.5×50	1	KM, KDX
29	N000011	Nut M16×1.5	1	KDL, KM, KDX
30	400070	Bearing 6208-2RZ	1	KDX, KDXP
31	OS000011	Oil seal 40×80×10	1	KDX, KDXP
32	S000009	Circlip for hole 80	1	KDX, KDXP
33	400073	Drive shaft support plate	1	KDX
34	B000097	Bolt M14×40	2	KM, KDX, KDXP
35	W000016	Washer M14	4	KDL, KDLP, KM, KDX, KDXP, KSP
36	W000011	Big washer M14	2	KM, KDX
37	N000032	Lock nut M14	N	KDL, KDLP, KM, KDX, KDXP, KS, KSP
38	400078	(Left) Roller protect	1	KDL, KDX
39	N000031	Lock nut M12	6	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
40	W000015	Washer 12	14	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
41	400081	Belt cover	1	KDX
42	400082	Hanging plate (Left)	1	KDL, KDX
43	400083	Tension 40×80	2	KDL, KDLP, KDX, KDXP
44	400084	Big pulley	1	KDLP, KDX, KDXP
45	400085	Belt 17×1260	4	KDX
46	400086	Small pulley	1	KDLP, KDX, KDXP

KDX series

Ser.No	Code	Name & Specification	Quantity	Remarks
47	500054	Back roller for 180	1	KDL, KDLP, KDX, KDXP
	400087	Back roller for 200	1	KDL, KDLP, KDX, KDXP
	400088	Back roller for 220	1	KDL, KDLP, KDX, KDXP
	400089	Back roller for 240	1	KDX, KDXP
48	418000	Main body for 180	1	KDX
	400090	Main body for 200	1	KDX
	400092	Main body for 240	1	KDX
49	400093	PTO Shaft 05B1000	1	KDX, KDXP
50	400094	Adjust plate (Right)	1	KDL, KDLP, KDX, KDXP, KMHP
51	P000005	Cotter pin Ø4×25	2	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
52	500110	Baffle shaft for 180	1	KDL, KDLP, KDX, KDXP
	400096	Baffle shaft for 200	1	KDL, KDLP, KDX, KDXP
	400097	Baffle shaft for 220	1	KDL, KDLP, KDX, KDXP
	400098	Baffle shaft for 240	1	KDX, KDXP
53	N000034	Lock nut M18	2	KDL, KDLP, KDX, KDXP
54	400100	Big baffle	N	KDL, KDX
55	400101	Combination bolt M16×40	8	KDL, KDLP, KDX, KDXP
56	OS000009	Oil seal 45×80×10	2	KDL, KDLP, KDX, KDXP
57	400103	Bearing housing	2	KDL, KDLP, KDX, KDXP
58	410000	Main roller for 180	1	KDLP, KDX, KDXP
	400104	Main roller for 200	1	KDLP, KDX, KDXP
	400105	Main roller for 220	1	KDLP, KDX, KDXP
	400106	Main roller for 240	1	KDX, KDXP
59	B000039	Bolt M14×90 (10.9)	N	KDL, KDLP, KDX, KDXP
60	400108	Hammer (14 mm Hole)	N	KDL, KDLP, KDX, KDXP
61	400109	Lubrication hose	1	KDL, KDX
62	400110	Small baffle	N	KDL, KDX
63	400111	Adjust plate (Left)	1	KDL, KDLP, KDX, KDXP, KMHP
64	B000085	Bolt M12×35	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
65	OS000010	Oil seal 40×90×10	1	KDL, KDLP, KDX, KDXP
66	000029	Instructions box	1	Optional
67	W000024	Spring washer M6	3	Optional
68	B000143	Cross pan head screws M6×16	3	Optional
69	W000025	Washer 6	3	Optional

ASSEMBLY DRAWING LIST




KDX PROFI three-point linkage

Ser.No	Code	Name & Specification	Quantity	Remarks
1	100002	Hook	1	KDL, KDLP, KDS, KDX, KDXP, KM, KMHP, KSP
2	100003	Lock pin	1	KDL, KDLP, KDX, KDXP, KM, KMHP
3	400038	Upper linkage pin	1	KDL, KDX, KDXP
4	700004	Linkage	1	KDXP
5	400034	Lock pin 4.5	2	KDLP, KDX, KDXP
6	700006	Lower linkage pin	2	KDXP
7	700007	Support parts	4	KDXP
8	200004	Quick connector cover	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
9	200005	Hose Quick connector G1/2	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
10	200006	Combination washer G1/2	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
11	200010	Hose 1900 mm	1	KMH, KMHP, KDX, KDXP, KSHP
12	200007	Hose 1500 mm	1	KMH, KMHP, KDX, KDXP, KSHP
13	N000012	Nut M18x1.5	1	KMH, KMHP, KDX, KDXP, KSHP

KDX PROFI three-point linkage

Ser.No	Code	Name & Specification	Quantity	Remarks
14	W000005	Spring washer M18	1	KMH, KMHP, KDX, KDXP, KSHP
15	200013	Cylinder sleeve	1	KMH, KMHP, KDX, KDXP, KSHP
16	200008	Hollow bolt	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
17	200009	Combination washer 12	4	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, RS, KSHP
18	400028	Hydraulic cylinder	1	KDX220-240, KDXP180-240
19	N000018	Thin nut M18×1.5	2	KMH, KMHP, KDX, KDXP, KSHP
20	400021	Slide pipe	2	KDX220-240, KDXP180-240
21	400016	Self-lubricating bearing 60×65×50	4	KDX220-240, KDXP180-240
22	S000016	Circlip for hole 65	4	KDX220-240, KDXP180-240
23	N000030	Lock nut M10	4	KDL, KDLP, KDS, KMHP, KDX, KDXP, KS, RS, KSP
24	W000014	Washer M10	8	KDL, KDLP, KDS, KMHP, KDX, KDXP, KS, RS, KSP
25	B000016	Bolt M10×110	4	KDX220-240, KDXP180-240
26	B000103	Bolt M16×45	8	KDL, KDX, KDXP
27	W000017	Washer M16	16	KDL, KDLP, KDX, KDXP
28	N000033	Lock nut M16	8	KDL, KDLP, KDX, KDXP, KM, KMHP, KSP

ASSEMBLY DRAWING LIST



KDX PROFI series

Ser.No	Code	Name & Specification	Quantity	Remarks
1	W000010	Big washer M12	5	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KSP
2	W000002	Spring washer M12	9	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, RS
3	B000084	Bolt M12x30	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, RS
4	400044	Shaft protection	1	KMHP, KDX, KDXP
5	K000009	Key A10x65	1	KM, KMHP, KDX, KDXP
6	B000073	Bolt M10x16	8	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP
7	W000001	Spring washer M10	8	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
8	W000009	Big washer M10	8	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, KSP
9	600078	Grease Nipples M10	3	KDL, KDLP, KDX, KDXP, KMHP, RS
10	B000102	Bolt M16x40	4	KDLP, KDXP
11	W000017	Washer M16	8	KDL, KDLP, KDX, KDXP
12	N000033	Lock nut M16	4	KDL, KDLP, KDX, KDXP, KM, KMHP, KSP
13	700041	Roller connect plate (Right)	1	KDXP, KDLP

KDX PROFI series

Ser.No	Code	Name & Specification	Quantity	Remarks
14	S000010	Circlip for hole 90	4	KDL, KDLP, KDX, KDXP
15	OS000008	Oil seal 45x90x10	2	KDL, KDLP, KDX, KDXP
16	400063	Bearing 6308-RZ	4	KDL, KDLP, KDX, KDXP
17	400366	Drive shaft tube for 180	1	KDXP180
	400066	Drive shaft tube for 200/220	1	KDX200-220, KDXP200-220
	400067	Drive shaft tube for 240	1	KDX240, KDXP240
18	700047	Drive shaft support plate	1	KDXP
19	B000097	Bolt M14x40	3	KM, KDX, KDXP
20	W000016	Washer M14	8	KDL, KDLP, KM, KDX, KDXP, KSP
21	N000032	Lock nut M14	N	KDL, KDLP, KM, KDX, KDXP, KS, KSP
22	500054	Back roller for 180	1	KDL, KDX, KDXP
	400087	Back roller for 200	1	KDL, KDX, KDXP
	400088	Back roller for 220	1	KDL, KDX, KDXP
	400089	Back roller for 240	1	KDX, KDXP
23	700054	Roller connect plate (Left)	1	KDLP, KDXP
24	700055	Round tip set	1	KDXP
25	S000017	Circlip for hole 40	1	KDXP
26	B000083	Bolt M12x25	1	KDL, KDXP
27	700058	Self-lubricating bearing 25x28x30	2	KDXP
28	700059	Tension wheel	1	KDXP
29	S000018	Circlip for hole 30	1	KDXP, RS
30	700061	Bearing 6306-2RZ	2	KDXP
31	S000008	Circlip for hole 72	1	KDXP
32	700063	Tensioning device	1	KDXP
33	700064	Tensioning spring	1	KDXP
34	000094	Grease Nipples M6	1	KDXP, KS, KSP
35	700066	Belt 17x1270	4	KDLP, KDXP
36	400083	Tension 40x80	2	KDL, KDLP, KDX, KDXP
37	400086	Small pulley	1	KDLP, KDX, KDXP
38	400084	Big pulley	1	KDLP, KDX, KDXP
39	OS000011	Oil seal 40x80x10	1	KDX, KDXP
40	S000009	Circlip for hole 80	1	KDX, KDXP
41	400070	Bearing 6208-2RZ	1	KDX, KDXP
42	718000	Main body for 180	1	KDXP
	700073	Main body for 200	1	KDXP
	700074	Main body for 220	1	KDXP
	700075	Main body for 240	1	KDXP


KDX PROFI series

Ser.No	Code	Name & Specification	Quantity	Remarks
43	400349	Drive shaft for 180		KDXP180
	400049	Drive shaft for 200/220	1	KDX200-220, KDXP200-220
	400050	Drive shaft for 240	1	KDX240, KDXP240
44	B000143	Cross pan head screws M6×16	3	KDLP, KDXP, KS
45	W000024	Spring washer M6	3	KDLP, KDXP, KS
46	W000025	Washer M6	3	KDLP, KDXP, KS, KSP
47	000029	Instructions box	1	KDLP, KDXP
48	100060	Drive shaft tube	1	KM, KMHP, KDX, KDXP
49	K000001	Key A10×40	1	KM, KMHP, KDX, KDXP
50	B000146	Hex cylinder head screw M12×35	4	KM, KMHP, KDX, KDXP
51	100030	Paper washer	1	KM, KMHP, KDX, KDXP
52	400042	Gearbox	1	KMHP, KDX, KDXP
53	400093	PTO Shaft 05B1000	1	KDX, KDXP
54	000024	PTO protection	1	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KSP
55	000030	Gearbox shaft cover	1	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS
56	N000031	Lock nut M12	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
57	W000015	Washer M12	8	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
58	B000085	Bolt M12×35	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
59	400111	Adjust plate (Left)	1	KDL, KDLP, KDX, KDXP, KMHP
60	P000005	Cotter pin Ø4×25	2	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
61	N000034	Lock nut M18	2	KDL, KDLP, KDX, KDXP
62	500110	Baffle shaft for 180	1	KDL, KDLP, KDX, KDXP
	400096	Baffle shaft for 200	1	KDL, KDLP, KDX, KDXP
	400097	Baffle shaft for 220	1	KDL, KDLP, KDX, KDXP
	400098	Baffle shaft for 240	1	KDX, KDXP
63	700099	Big baffle	N	KDLP, KDXP
64	OS000009	Oil seal 45×80×10	2	KDL, KDLP, KDX, KDXP
65	400101	Combination bolt M16×40	8	KDL, KDLP, KDX, KDXP
66	400103	Bearing housing	2	KDL, KDLP, KDX, KDXP
67	B000039	Bolt M14×90 (10.9)	N	KDL, KDLP, KDX, KDXP
68	400108	Hammer (14 mm Hole)	N	KDL, KDLP, KDX, KDXP
69	410000	Main roller for 180	1	KDLP, KDX, KDXP
	400104	Main roller for 200	1	KDLP, KDX, KDXP
	400105	Main roller for 220	1	KDLP, KDX, KDXP
	400106	Main roller for 240	1	KDX, KDXP
70	700108	Small baffle	N	KDLP, KDXP
71	400094	Adjust plate (Right)	1	KDL, KDLP, KDX, KDXP, KMHP
72	700110	Lubrication hose	1	KDXP
73	B000148	Rivet Ø4×8	6	KDXP
74	700112	Plate for belt protection	1	KDXP
75	700113	U-shaped sealing strip 0,3 m	0.3m	KDXP

KDX PROFI series

Ser.No	Code	Name & Specification	Quantity	Remarks
76	OS000010	Oil seal 40×90×10	1	KDL, KDLP, KDX, KDXP
77	700115	Belt cover	1	KDXP
78	700116	U-shaped sealing strip 0,7 m	0.7m	KDXP
79	N000030	Lock nut M10	4	KDL, KDLP, KDS, KMHP, KDX, KDXP, KS, RS, KSP
80	W000014	Washer M10	8	KDL, KDLP, KDS, KMHP, KDX, KDXP, KS, RS, KSP
81	B000076	Bolt M10×30	4	KDL, KDS, KDXP, RS, KSP


ASSEMBLY DRAWING LIST



KM three-point linkage

Ser.No	Code	Name & Specification	Quantity	Remarks
1	000001	Upper linkage pin	1	KDS, KM, KMHP, KS, RS, KSP
2	100002	Hook	1	KDL, KDLP, KDS, KDX, KDXP, KM, KMHP, KSP
3	100003	Lock pin	4	KDL, KDLP, KDX, KDXP, KM, KMHP
4	100004	Lower linkage pin	2	KM, KMHP
5	100005	Mounting plate	4	KM
6	100006	Linkage	1	KM
7	N000031	Lock nut M12	8	KDL, KDS, KM, KMHP, KDX, KDXP, KS, KSP
8	W000015	Washer M12	16	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
9	B000086	Bolt M12×40	8	KDLP, KDS, KM, KMHP, RS, KSP

ASSEMBLY DRAWING LIST




KMH three-point linkage

Ser.No	Code	Name & Specification	Quantity	Remarks
1	100006	Linkage	1	KM
2	000001	Upper linkage pin	1	KDS, KM, KMHP, KS, RS, KSP
3	100002	Hook	1	KDL, KDLP, KDS, KDX, KDXP, KM, KMHP, KSP
4	200004	Quick connector cover	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
5	200005	Hose Quick connector G1/2	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
6	200006	Combination washer G1/2	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
7	200007	Hose 1500 mm	1	KMH, KMHP, KDX, KDXP, KSHP
8	200008	Hollow bolt	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
9	200009	Combination washer 12	4	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, RS, KSHP
10	200010	Hose 1900 mm	1	KMH, KMHP, KDX, KDXP, KSHP
11	N000012	Nut M18x1.5	1	KMH, KMHP, KDX, KDXP, KSHP
12	W000005	Spring washer M18	1	KMH, KMHP, KDX, KDXP, KSHP
13	200013	Cylinder sleeve	1	KMH, KMHP, KDX, KDXP, KSHP

KMH three-point linkage

Ser.No	Code	Name & Specification	Quantity	Remarks
14	200014	Hydraulic cylinder	1	KDX180-200, KMH, KMHP
15	200015	Suspension connection plate	1	KMH
16	N000018	Nut M18×1.5	2	KMH, KMHP, KDX, KDXP, KSHP
17	N000031	Lock nut M12	20	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
18	W000015	Washer M12	40	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
19	B000085	Bolt M12×35	8	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
20	100003	Lock pin	4	KDL, KDLP, KDX, KDXP, KM, KMHP
21	100004	Lower linkage pin	2	KM, KMHP
22	200022	Slide pipe	2	KMH, KMHP
23	200023	Self-lubricating bearing 40×44×50	4	KDX180-200, KDL, KDLP, KMH, KMHP, KSHP
24	S000015	Circlip for hole 45	4	KDX180-200, KMH, KMHP, KSHP
25	200025	(Left) Support plate	1	KMH
26	100005	Mounting plate	4	KM
27	200027	(Right) Support plate	1	KMH
28	B000029	Bolt M12×70	4	KMH, KMHP, KSHP
29	B000086	Bolt M12×40	8	KDLP, KDS, KM, KMHP, RS, KSP

ASSEMBLY DRAWING LIST



KM series

Ser.No	Code	Name & Specification	Quantity	Remarks
1	000028	PTO shaft 04B1000	1	KM, KMHP, KS, KSP
2	W000010	Big washer M12	5	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KSP
3	W000002	Spring washer M12	9	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, RS
4	B000084	Bolt M12×30	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, RS
5	W000025	Washer M6	3	Optional
6	W000024	Spring washer M6	3	Optional
7	B000143	Cross pan head screws M6×16	3	Optional
8	N000031	Lock nut M12	12	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
9	W000015	Washer M12	26	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
10	B000085	Bolt M12×35	12	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
11	B000138	Hexagon socket countersunk head screws M8×25	10	KDS, KM, KMHP


KM series

Ser.No	Code	Name & Specification	Quantity	Remarks
12	W000021	Washer M8	2	KDL, KDLP, KDS, KM, KMHP, KS, RS
13	N000039	Lock nut M8	2	KDL, KDLP, KDS, KM, KMHP, KS, RS
14	100023	Roller connect plate (Right)	1	KM, KMHP
15	100024	Scraper for 125	1	KM, KS
	100025	Scraper for 155	1	KM, KMHP
	100026	Scraper for 175	1	KM, KMHP
16	100027	Bracket for gearbox	1	KM
17	100028	Bearings UC205	2	KDS, KM, KMHP
18	100029	Gearbox	1	KDS, KM
19	100030	Paper washer	1	KM, KMHP, KDX, KDXP
20	100031	Back roller for 125	1	KDS, KM
	100032	Back roller for 155	1	KM, KMHP
	100033	Back roller for 175	1	KM, KMHP
21	B000146	Hex cylinder head screw M12×35	4	KM, KMHP, KDX, KDXP
22	100035	Drive shaft for 125	1	KM125
	100036	Drive shaft for 155	1	KM155
	100037	Drive shaft 155-175	1	KM175, KMHP155-175
23	100038	Bearing 6007-2RZ	1	KM, KMHP, KSMP
24	OS000002	Oil seal 35×62×10	1	KM, KMHP, KSP
25	100040	Roller connect plate (Left)	1	KM, KMHP
26	B000097	Bolt M14×40	2	KM, KDX, KDXP
27	W000016	Washer M14	2	KDL, KDLP, KM, KDX, KDXP, KSP
28	W000011	Big washer M14	2	KM, KDX
29	N000032	Lock nut M14	2	KDL, KDLP, KM, KDX, KDXP, KS, KSP
30	100045	Drive shaft support plate	1	KM
31	000056	Belt cover	1	KDS, KM, KMHP, KS, KSP
32	S000006	Circlip for hole 62	1	KM, KMHP, KSP
33	100048	Belt 17×1016	3	KM, KMHP
34	100049	Tension 35×60	2	KDS, KM, KMHP, KSP
35	100050	Big pulley	1	KM, KMHP
36	K000001	Key A10×40	1	KM, KMHP, KDX, KDXP
37	B000130	Bolt M16×1.5×50	1	KM, KDX
38	N000011	Nut M16×1.5	1	KDL, KM, KDX
39	100054	Drive shaft pipe for 125	1	KM125
	100055	Drive shaft pipe for 155	1	KM155
	100056	Drive shaft pipe for 175	1	KM175, KMHP155-175
40	100057	Main body for 125	1	KM
	100058	Main body for 155	1	KM
	100059	Main body for 175	1	KM
41	100060	Drive shaft tube	1	KM, KMHP, KDX, KDXP
42	000024	PTO protection	1	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KSP

KM series

Ser.No	Code	Name & Specification	Quantity	Remarks
43	K000009	Key A10×65	1	KM, KMHP, KDX, KDXP
44	W000009	Big washer M10	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, KSP
45	W000001	Spring washer M10	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
46	B000073	Bolt M10×16	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP
47	000030	Gearbox shaft cover	1	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, KSP
48	100067	Gearbox mounting plate	1	KM
49	000029	Instructions box	1	Optional
50	000082	Grease Nipples M8	2	KDLP, KDS, KM, KMHP, KS, KSP
51	100070	Adjust plate (Right)	1	KM
52	P000005	Cotter pin Ø4×25	2	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
53	N000033	Lock nut M16	N	KDL, KDLP, KDX, KDXP, KM, KMHP, KSP
54	100073	Composite bolt M12×30	8	KDS, KM, KMHP
55	100074	Bearings UC207	2	KDS, KM, KMHP
56	B000047	Bolt M16×85 (10.9 Level)	N	KM, KMHP
57	100076	Y Blade Connector	2N	KDL, KM, KMHP, KDX, KDXP
58	100077	Y Blade	2N	KDL, KM, KMHP, KDX, KDXP
59	100078	Main roller for 125	1	KM
	100079	Main roller for 155	1	KM, KMHP
	100080	Main roller for 175	1	KM, KMHP
60	000070	Big baffle	N	KDS, KM, KMHP, KS, KSP
61	100082	Hammer	N	KM, KMHP
62	OS000005	Oil seal 55×80×10	1	KDS, KM, KMHP
63	000069	Small baffle	N	KDS, KM, KMHP, KS, KSP
64	100085	Baffle shaft for 125	1	KM, KDS
	100086	Baffle shaft for 155	1	KM, KMHP
	100087	Baffle shaft for 175	1	KM, KMHP
65	100088	Adjust plate (Left)	1	KM
66	100089	Sleeve	1	KDS, KM, KMHP
67	100090	Small pulley	1	KM, KMHP
68	000062	Support tube plug	1	KDS, KM, KMHP, KS, RS, KSP
69	000063	R pin Ø3.5	1	KDL, KDLP, KDS, KM, KMHP, KS, RS, KSP
70	000064	Pin for support foot	1	KDL, KDLP, KDS, KM, KMHP, KS, RS, KSP
71	000065	Support foot	1	KM, KMHP, KS
72	000055	Rubber	1	KDS, KM, KMHP, KS, KSP
73	B000025	Bolt M12×120	1	KDS, KM, KMHP

ASSEMBLY DRAWING LIST




KMH PROFI three-point linkage

Ser.No	Code	Name & Specification	Quantity	Remarks
1	000001	Upper linkage pin	1	KDS, KM, KMHP, KS, RS, KSP
2	600002	Upper linkage parts	1	KMHP
3	W000015	Washer M12	32	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
4	N000031	Lock nut M12	16	KDL, KDS, KM, KMHP, KDX, KDXP, KS, KSP
5	B000086	Bolt M12x40	12	KDLP, KDS, KM, KMHP, RS, KSP
6	600006	Linkage	1	KMHP
7	100002	Hook	1	KDL, KDLP, KDS, KDX, KDXP, KM, KMHP, KSP
8	600008	Support parts	4	KMHP
9	100003	Lock pin	4	KDL, KDLP, KDX, KDXP, KM, KMHP
10	100004	Lower linkage pin	2	KM, KMHP

KMH PROFI three-point linkage

Ser.No	Code	Name & Specification	Quantity	Remarks
11	200004	Quick connector cover	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
12	200005	Hose Quick connector G1/2	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
13	200006	Combination washer G1/2	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
14	200007	Hose 1500 mm	1	KMH, KMHP, KDX, KDXP, KSHP
15	200010	Hose 1900 mm	1	KMH, KMHP, KDX, KDXP, KSHP
16	200008	Hollow bolt	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
17	200009	Combination washer 12	4	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, RS, KSHP
18	N000012	Nut M18×1.5	1	KMH, KMHP, KDX, KDXP, KSHP
19	W000005	Spring washer M18	1	KMH, KMHP, KDX, KDXP, KSHP
20	200013	Cylinder sleeve	1	KMH, KMHP, KDX, KDXP, KSHP
21	200014	Hydraulic cylinder	1	KDX180-200, KMH, KMHP
22	N000018	Thin nut M18×1.5	2	KMH, KMHP, KDX, KDXP, KSHP
23	200022	Slide pipe	2	KMH, KMHP
24	200023	Self-lubricating bearing 40×44×50	4	KDX180-200, KDL, KDLP, KMH, KMHP, KSHP
25	S000015	Circlip for hole 45	4	KDX180-200, KMH, KMHP, KSHP
26	B000029	Bolt M12×70	4	KMH, KMHP, KSHP

ASSEMBLY DRAWING LIST



KMH PROFI series

Ser.No	Code	Name & Specification	Quantity	Remarks
1	B000154	Bolt M10×75	2	KMHP, KSP
2	W000014	Washer M10	8	KDL, KDLP, KDS, KMHP, KDX, KDXP, KS, RS, KSP
3	N000001	Nut M10	6	KMHP, KS, KDLP, KSP
4	W000009	Big washer M10	9	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, KSP
5	W000010	Big washer M12	9	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KSP
6	W000002	Spring washer M12	13	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, RS
7	B000084	Bolt M12×30	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, RS
8	400042	Gearbox	1	KMHP, KDX, KDXP
9	400044	Shaft protection	1	KMHP, KDX, KDXP
10	100023	Roller connect plate (Right)	1	KMH, KMHP
11	100028	Bearings UC205	2	KDS, KM, KMHP
12	W000001	Spring washer M10	8	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP


KMH PROFI series

Ser.No	Code	Name & Specification	Quantity	Remarks
13	B000073	Bolt M10×16	8	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP
14	100056	Drive shaft pipe	1	KM175, KMHP155-175
15	100032	Back roller for 155	1	KM, KMHP
	100033	Back roller for 175	1	KM, KMHP
16	100037	Drive shaft 155-175	1	KM175, KMHP155-175
17	100025	Scraper for 155	1	KM, KMHP
	100026	Scraper for 175	1	KM, KMHP
18	100038	Bearing 6007-2RZ	1	KM, KMHP, KSP
19	OS000002	Oil seal 35×62×10	1	KM, KMHP, KSP
20	100040	Roller connect plate (Left)	1	KM, KMHP
21	B000138	Hexagon socket countersunk head screws M8×25	10	KDS, KM, KMHP
22	W000021	Washer M8	4	KDL, KDLP, KDS, KM, KMHP, KS, RS
23	N000039	Lock nut M8	2	KDL, KDLP, KDS, KM, KMHP, KS, RS
24	N000031	Lock nut M12	8	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
25	W000015	Washer M12	18	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
26	B000085	Bolt M12×35	12	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
27	B000077	Bolt M10×35	2	KMHP, RS
28	N000030	Lock nut M10	2	KDL, KDLP, KDS, KMHP, KDX, KDXP, KS, RS, KSP
29	000056	Belt cover	1	KDS, KM, KMHP, KS, KSP
30	B000025	Bolt M12×120	1	KDS, KM, KMHP
31	000055	Rubber	1	KDS, KM, KMHP, KS, KSP
32	100048	Belt 17×1016	3	KM, KMHP
33	B000109	Bolt M8×16	2	KDL, KDLP, KMHP, KS, KSP
34	W000008	Spring washer M8	2	KDL, KMHP, KS, RS, KSP
35	600063	T cover	1	KMHP
36	100090	Small pulley	1	KM, KMHP
37	100049	Tension 35×60	2	KDS, KM, KMHP, KSP
38	100050	Big pulley	1	KM, KMHP
39	600067	Drive shaft support plate	1	KMHP
40	S000006	Circlip for hole 62	1	KM, KMHP, KSP
41	K000001	Key A10×40	1	KM, KMHP, KDX, KDXP
42	B000146	Hex cylinder head screw	4	KM, KMHP, KDX, KDXP
43	100060	Drive shaft tube	1	KM, KMHP, KDX, KDXP
44	100030	Paper washer	1	KM, KMHP, KDX, KDXP
45	K000009	Key A10×65	1	KM, KMHP, KDX, KDXP
46	000030	Gearbox shaft cover	1	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, KSP
47	600075	Bracket for gearbox	1	KMHP
48	000024	PTO protection	1	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KSP
49	400094	Adjust plate (Right)	1	KDL, KDLP, KDX, KDXP, KMHP

KMH PROFI series

Ser.No	Code	Name & Specification	Quantity	Remarks
50	600078	Grease Nipples M10	1	KDL, KDLP, KDX, KDXP, KMHP, RS
51	000064	Pin for support foot	1	KDL, KDLP, KDS, KM, KMHP, KS, RS, KSP
52	000063	R pin Ø3.5	1	KDL, KDLP, KDS, KM, KMHP, KS, KSP
53	000062	Support tube plug	1	KDS, KM, KMHP, KS, RS, KSP
54	000065	Support foot	1	KM, KMHP, KS
55	P000005	Cotter pin Ø4x25	2	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
56	N000033	Lock nut M16	N	KDL, KDLP, KDX, KDXP, KM, KMHP, KSP
57	100086	Baffle shaft for 155	1	KM, KMHP
	100087	Baffle shaft for 175	1	KM, KMHP
58	600087	Main body for 155	1	KMHP
	600088	Main body for 175	1	KMHP
59	000070	Big baffle	N	KDS, KM, KMHP, KS, KSP, RS
60	100073	Composite bolt M12x30	8	KDS, KM, KMHP
61	100074	Bearings UC207	2	KDS, KM, KMHP
62	B000047	Bolt M16x85 (10.9 Level)	N	KM, KMHP
63	100076	Y blade Connector	N	KDL, KM, KMHP, KDX, KDXP
64	100077	Y Blade	N	KDL, KM, KMHP, KDX, KDXP
65	100082	Hammer	N	KM, KMHP
66	000082	Grease Nipples M8	1	KDLP, KDS, KM, KMHP, KS, KSP
67	OS000005	Oil seal 55x80x10	1	KDS, KM, KMHP
68	100089	Sleeve	1	KDS, KM, KMHP
69	000069	Small baffle	N	KDS, KM, KMHP, KS, KSP
70	400111	Adjust plate (Left)	1	KDL, KDLP, KDX, KDXP, KMHP
71	000028	PTO Shaft 04B1000	1	KM, KMHP, KS, KSP
72	100079	Main roller for 155	1	KM, KMHP
	100080	Main roller for 175	1	KM, KMHP


ASSEMBLY DRAWING LIST



KS three-point linkage

Ser.No	Code	Name & Specification	Quantity	Remarks
1	000001	Upper linkage pin	1	KDS, KM, KMHP, KS, RS, KSP
2	000002	Upper linkage parts	1	KS
3	000003	Linkage plate (Right)	1	KS
4	B000085	Bolt M12×35	10	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
5	W000015	Washer M12	20	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
6	N000031	Lock nut M12	10	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
7	000007	Linkage plate (Left)	1	KS
8	000008	Hook	1	KS

ASSEMBLY DRAWING LIST



KS series

Ser.No	Code	Name & Specification	Quantity	Remarks
1	B000111	Bolt M8×25	14	KDLP, KS, RS
2	W000021	Washer M8	21	KDL, KDLP, KDS, KM, KMHP, KS, RS
3	N000039	Lock nut M8	14	KDL, KDLP, KDS, KM, KMHP, KS, RS
4	S000003	Circlip for hole 47	2	KS
5	OS000001	Oil seal 25×47×7	2	KS
6	000014	Bearing 6204-2RZ	2	KS
7	000015	Scraper for 95	1	KS
	000016	Scraper for 115	1	KS
	100024	Scraper for 125	1	KM, KS
	000018	Scraper for 135	1	KS


KS series

Ser.No	Code	Name & Specification	Quantity	Remarks
8	000019	Back roller for 95	1	KS
	000020	Back roller for 115	1	KS
	000021	Back roller for 125	1	KS
	000022	Back roller for 135	1	KS
9	000023	Roller connect plate (Right)	1	KS
10	001924	PTO protection	1	KS
11	W000013	Big washer M8	9	KDL, KDLP, KS, RS, KSP
12	W000008	Spring washer M8	2	KDL, KDLP, KMHP, KS, RS, KSP
13	B000109	Bolt M8×16	2	KDL, KDLP, KMHP, KS, KSP
14	000028	PTO Shaft 04B1000	1	KM, KMHP, KS, KSP
15	000029	Instructions box	1	Optional
16	000030	Gearbox shaft cover	1	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, KSP
17	000031	Gearbox	1	KS, KSP
18	K000004	Key 10×45	1	KS, KSP
19	000033	Drive shaft tube	1	KS, KSP
20	K000003	Key 10×30	1	KS, KSP
21	000035	Drive shaft	1	KS95-115
	000036	Drive shaft	1	KS125-135
22	000037	Bearings UC205	1	KS
23	000038	Composite bolt M8×25	12	KS, KSP
24	N000001	Nut M10	2	KMHP, KS, KDLP, KSP
25	B000081	Bolt M10×70	1	KS
26	000041	Roller connect plate (Left)	1	KS
27	B000078	Bolt M10×40	4	KS, KSP
28	W000014	Washer M10	10	KDL, KDLP, KDS, KMHP, KDX, KDXP, KS, RS, KSP
29	N000030	Lock nut M10	4	KDL, KDLP, KDS, KMHP, KDX, KDXP, KS, RS, KSP
30	B000143	Cross pan head screws M6×16	7	Optional
31	W000024	Spring washer M6	7	Optional
32	W000025	Washer M6	7	Optional
33	000048	Bracket for gearbox	1	KS95-115
	000049	Bracket for gearbox	1	KS125-135
34	000050	Big pulley	1	KS
35	000051	Drive shaft cover	1	KS95-115
	000052	Drive shaft cover	1	KS125-135
36	000053	Tension 22×47	2	KS, KSP
37	000054	Belt 13×930	3	KS, KSP
38	000055	Rubber	2	KDS, KM, KMHP, KS, KSP
39	000056	Belt cover	1	KDS, KM, KMHP, KS, KSP
40	W000001	Spring washer M10	1	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
41	W000009	Big washer M10	1	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, KSP
42	B000017	Bolt M10×120	1	KS, KSP

KS series

Ser.No	Code	Name & Specification	Quantity	Remarks
43	000060	Small pulley	1	KS, KSP
44	000061	Sleeve	1	KS, KSP
45	000062	Support tube plug	1	KDS, KM, KMHP, KS, RS, KSP
46	000063	R pin Ø3.5	1	KDL, KDLP, KDS, KM, KMHP, KS, KSP
47	000064	Pin for support foot	1	KDL, KDLP, KDS, KM, KMHP, KS, RS, KSP
48	000065	Support foot	1	KM, KMHP, KS
49	000066	Adjust plate (Left)	1	KS
50	P000005	Cotter pin Ø4×25	2	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
51	N000032	Lock nut M14	2	KDL, KDLP, KM, KDX, KDXP, KS, KSP
52	000069	Small baffle	N	KDS, KM, KMHP, KS, KSP
53	000070	Big baffle	N	KDS, KM, KMHP, KS, KSP
54	000071	Baffle shaft for 95	1	KS, KSP
	000072	Baffle shaft for 115	1	KS, KSP
	000073	Baffle shaft for 125	1	KS, KSP
	000074	Baffle shaft for 135	1	KS, KSP
55	000075	Lower linkage pin sleeve	2	KS, RS
56	000076	Lower linkage pin	2	KS, RS
57	000077	Main body for 95	1	KS
	000078	Main body for 115	1	KS
	000079	Main body for 125	1	KS
	000080	Main body for 135	1	KS
58	000081	Adjust plate (Right)	1	KS
59	000082	Grease Nipples M8	1	KDLP, KDS, KM, KMHP, KS, KSP
60	000083	Bearings UC205	2	KS, KSP
61	B000030	Bolt M12×75 (10.9Level)	N	KS, KSP
62	000085	Y blade Connector	2	KDS, KS, KSP
63	000086	Y Blade	2	KDS, KS, KSP
64	N000031	Lock nut M12	N	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
65	000088	Main roller for 95	1	KS, KSP
	000089	Main roller for 115	1	KS, KSP
	000090	Main roller for 125	1	KS, KSP
	000091	Main roller for 135	1	KS, KSP
66	000092	Hammer	N	KS, KSP
67	OS000006	Oil seal 40×55×10	1	KS, KSP
68	000094	Grease Nipples M6	1	KDXP, KS, KSP


ASSEMBLY DRAWING LIST



KS PROFI three-point linkage

Ser.No	Code	Name & Specification	Quantity	Remarks
1	100002	Hook	1	KDL, KDLP, KDS, KDX, KDXP, KM, KMHP, KSP
2	110000	Linkage	1	KSP
3	000001	Upper linkage pin	1	KDS, KM, KMHP, KS, RS, KSP
4	W000016	Washer M14	8	KDL, KDLP, KM, KDX, KDXP, KSP
5	N000032	Lock nut M14	4	KDL, KDLP, KM, KDX, KDXP, KS, KSP
6	N000031	Lock nut M12	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
7	W000015	Washer M12	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
8	W000010	Big washer M12	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KSP
9	B000085	Bolt M12x35	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
10	110001	Linkage plate (Right)	1	KSP
11	300014	Lower linkage pin	2	KDS, KSP
12	110002	Lower linkage plate	2	KSP
13	B000155	Bolt M14x100	4	RS, KSP
14	110003	Linkage plate (Left)	1	KSP

ASSEMBLY DRAWING LIST




KSHP PROFI three-point linkage

Ser.No	Code	Name & Specification	Quantity	Remarks
1	200004	Quick change connector cover	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
2	200005	Hose Quick connector G1/2	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
3	200006	Combination washer G1/2	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
4	200010	Hose 1900mm	1	KMH, KMHP, KDX, KDXP, KSHP
5	200008	Hollow bolt	2	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, KSHP
6	200009	Combination washer 12	4	KDL, KDLP, KDS, KDX, KDXP, KMH, KMHP, RS, KSHP
7	N000018	Nut M18x1.5	2	KMH, KMHP, KDX, KDXP, KSHP
8	110093	Cylinder holder	1	KSHP
9	N000031	Lock nut M12	10	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
10	W000015	Washer M12	16	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
11	B000085	Bolt M12x35	6	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP

KSHP PROFI three-point linkage

Ser.No	Code	Name & Specification	Quantity	Remarks
12	110094	Cylinder	1	KSHP
13	200013	Cylinder sleeve	1	KMH, KMHP, KDX, KDXP, KSHP
14	200007	Hose 1500 mm	1	KMH, KMHP, KDX, KDXP, KSHP
15	W000005	Spring washer M18	1	KMH, KMHP, KDX, KDXP, KSHP
16	N000012	Nut M18×1.5	1	KMH, KMHP, KDX, KDXP, KSHP
17	S000015	Circlip for hole 45	4	KDX180-200, KMH, KMHP, KSHP
18	200023	Self-lubricating bearing 40×44×50	4	KDX180-200, KDL, KDLP, KMH, KMHP, KSHP
19	110095	Linkage tube	1	KSHP
20	300014	Lower linkage pin	2	KDS, KSP
21	B000029	Bolt M12×70	4	KMH, KMHP, KSHP
22	W000010	Big washer M12	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KSP
23	110096	Support parts (Right)	1	KSHP
24	110097	Slide pipe	2	KSHP
25	110098	Support parts (Left)	1	KSHP
26	100002	Hook	1	KDL, KDLP, KDS, KDX, KDXP, KM, KMHP, KSP
27	B000155	Bolt M14x100	4	RS, KSP
28	W000016	Washer M14	8	KDL, KDLP, KM, KDX, KDXP, KSP
29	N000032	Lock nut M14	4	KDL, KDLP, KM, KDX, KDXP, KS, KSP
30	110000	Linkage	1	KSP
31	000001	Upper linkage pin	1	KDS, KM, KMHP, KS, RS, KSP

ASSEMBLY DRAWING LIST



KS PROFI series

Ser.No	Code	Name & Specification	Quantity	Remarks
1	N000030	Lock nut M10	12	KDL, KDLP, KDS, KMHP, KDX, KDXP, KS, RS, KSP
2	W000014	Washer M10	26	KDL, KDLP, KDS, KMHP, KDX, KDXP, KS, RS, KSP
3	B000076	Bolt M10×30	4	KDL, KDS, KDXP, RS, KSP
4	000082	Grease Nipples M8	3	KDLP, KDS, KM, KMHP, KS, KSP
5	110004	Adjust plate (Right)	1	KSP
6	110005	Bearing 6205-RZ	2	KSP
7	110006	Back bearing roller cover	2	KSP
8	110007	Scraper for 95	1	KSP
	110008	Scraper for 105	1	KSP
	110009	Scraper for 115	1	KSP
	110010	Scraper for 125	1	KSP
	110011	Scraper for 135	1	KSP

KS PROFI series

Ser.No	Code	Name & Specification	Quantity	Remarks
9	110012	Back roller for 95	1	KSP
	110013	Back roller for 105	1	KSP
	110014	Back roller for 115	1	KSP
	110015	Back roller for 125	1	KSP
	110016	Back roller for 135	1	KSP
10	B000075	Bolt M10×25	2	KDS, RS, KSP
11	110018	Adjust plate (Left)	1	KSP
12	B000153	Special bolt M10×30	2	KSP
13	110020	Drive shaft support plate	1	KSP
14	N000001	Nut M10	6	KMHP, KS, KDLP, KSP
15	W000009	Big washer M10	3	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, KSP
16	B000154	Bolt M10×75	2	KSP
17	OS000002	Oil seal 35×62×10	1	KM, KMHP, KSP
18	S000006	Circlip for hole 62	1	KM, KMHP, KSP
19	100038	Bearing 6007-2RZ	1	KM, KMHP, KSP
20	110027	Drive shaft for 95-115	1	KSP
	110028	Drive shaft for 125-135	1	KSP
21	K000003	Key 10×30	1	KS, KSP
22	110030	Drive shaft tube for 95-115	1	KSP
	110031	Drive shaft tube for 125-135	1	KSP
23	B000113	Bolt M8×30	4	KDLP, KSP
24	W000008	Spring washer M8	6	KDL, KDLP, KMHP, KS, RS, KSP
25	000033	Drive shaft tube	1	KS, KSP
26	110035	Paper washer	1	KSP
27	K000004	Key 10×45	1	KS, KSP
28	000031	Gearbox	1	KS, KSP
29	B000078	Bolt M10×40	4	KS, KSP
30	110039	Bracket for gearbox	1	KSP
31	000030	Gearbox shaft cover	1	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, KSP
32	110041	Gearbox adjustment plate	1	KSP
33	N000031	Lock nut M12	2	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
34	W000015	Washer M12	4	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
35	B000086	Bolt M12×40	2	KDLP, KDS, KM, KMHP, RS, KSP
36	000024	PTO protection	1	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KSP
37	B000109	Bolt M8×16	2	KDL, KDLP, KMHP, KS, KSP
38	W000013	Big washer M8	2	KDL, KDLP, KS, RS, KSP

KS PROFI series

Ser.No	Code	Name & Specification	Quantity	Remarks
39	110049	Main body for 95	1	KSP
	110050	Main body for 105	1	KSP
	110051	Main body for 115	1	KSP
	110052	Main body for 125	1	KSP
	110053	Main body for 135	1	KSP
40	P000005	Cotter pin Ø4×25	2	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
41	N000033	Lock nut M16	2	KDL, KDLP, KDX, KDXP, KM, KMHP, KSP
42	000071	Baffle shaft for 95	1	KS, KSP
	110057	Baffle shaft for 105	1	KSP
	000072	Baffle shaft for 115	1	KS, KSP
	000073	Baffle shaft for 125	1	KS, KSP
	000074	Baffle shaft for 135	1	KS, KSP
43	000070	Big baffle	n	KDS, KM, KMHP, KS, KSP
44	000069	Small baffle	N	KDS, KM, KMHP, KS, KSP
45	000038	Composite bolt M8×25	8	KS, KSP
46	000083	Bearings UC205	2	KS, KSP
47	000092	Hammer	N	KS, KSP
48	000088	Main roller for 95	1	KS, KSP
	110067	Main roller for 105	1	KSP
	000089	Main roller for 115	1	KS, KSP
	000090	Main roller for 125	1	KS, KSP
	000091	Main roller for 135	1	KS, KSP
49	000085	Y blade Connector	n	KDS, KS, KSP
50	000086	Y Blade	n	KDS, KS, KSP
51	000094	Grease Nipples M6	1	KDXP, KS, KSP
52	OS000006	Oil seal 40×55×10	1	KS, KSP
53	000061	Sleeve	1	KS, KSP
54	B000013	Bolt M6×20	2	KSP
55	W000025	Washer M6	2	KDLP, KDXP, KS, KSP
56	N000043	Lock nut M6	2	KSP
57	110079	T cover	1	KSP
58	110080	Support foot	1	KSP
59	000064	Pin for support foot	1	KDL, KDLP, KDS, KM, KMHP, KS, RS, KSP
60	000063	R pin Ø3.5	1	KDL, KDLP, KDS, KM, KMHP, KS, RS, KSP
61	000056	Belt cover	1	KDS, KM, KMHP, KS, KSP
62	000055	Rubber	1	KDS, KM, KMHP, KS, KSP
63	W000001	Spring washer M10	1	KDL, KDLP, KDS, KM, KMHP, KDX, KDXP, KS, RS, KSP
64	B000017	Bolt M10×120	1	KS, KSP
65	000062	Support tube plug	1	KDS, KM, KMHP, KS, RS, KSP
66	000060	Small pulley	1	KS, KSP
67	000053	Tension 22×47	1	KS, KSP

KS PROFI series

Ser.No	Code	Name & Specification	Quantity	Remarks
68	000054	Belt 13×930	3	KS, KSP
69	100049	Tension 35×60	1	KDS, KM, KMHP, KSP
70	110092	Big pulley	1	KSP
71	000028	PTO Shaft 04B1000	1	KM, KMHP, KS, KSP
72	B000030	Bolt M12×75 (10.9)	N	KS, KSP